

Instructions for Tuning your receiver to the Optus D2 Satellite

Healing HSDS850

Before you begin identify the following buttons on the remote control for the satellite receiver:-

Menu, exit, OK, the up-down and left-right buttons, and the red, green, yellow and blue buttons.

Switch on the satellite receiver and TV as you normally would to watch one of the channels - now you are ready to begin:- First of all you need to delete the existing channels:-

To Delete existing Channels

1. Press **menu**
2. Select **Channel Manager** with the **up or down** buttons (When an item is selected it will be highlighted with yellow)
3. Press **OK**
4. Select **TV Channel** with the **up or down** buttons and press **OK**
5. Press the **red button** on the remote until it reads **x Delete all**
6. Press **OK** once so that every name has an **x** beside it
7. Press **exit**
8. Press **up button** so that **OK** is highlighted
9. Press **OK**
10. Repeat the above steps from 4 - 9 to delete the radio channels - select **Radio Channel** at step 4
11. Press **exit** - You should now be back to the **Main Menu**.

To scan in the channels:-

1. Ensure that you are in the **Main Menu**
2. Select **Installation** and press **OK**
3. Select **Channel Search** and press **OK**
4. Select **Transponder** and press the **red** button
5. Select **Frequency** and press the number keys **12706** in that order
6. Select **Symbol Rate** and press the number keys **22500**
7. Select **Polarization** and, if necessary, press the **left or right** button to select **Ver**
8. Select **Search Mode** and, if necessary, press the **left or right** button to select **FTA**
9. Select **Channel Type** and, if necessary, press the **left or right** button to select **TV & Radio**
10. Select **Search 1 Sat** and press **OK**
11. When the search has been completed **View CH** will be highlighted - press **OK**

To organize the channels:-

1. Press **menu**
2. Select **Channel Manager** with the **up or down** buttons and press **OK**
3. Select **TV Channel** with the **up or down** buttons and press **OK**
4. Press the **yellow** button on your remote to select **move**
5. Find the channel with the **up or down** buttons and press **OK** - the number of the channel should change to arrows
6. Use the **up or down** buttons to move the yellow highlight to where you want it & press **OK**
7. Repeat steps 4-6 for each channel you want to move.
8. When completed press the **exit** button 3 times and you have finished!

If you have another brand of satellite receiver, these are the new parameters for Optus D2 that will need to be entered in to your satellite receiver.

Freq 12,706 GHz
Symbol rate 22,500
Pol Vertical
FEC 3/4